


A Novel MicroElectroMechanical System (MEMS) Device for Passive Sampling of Hydrophobic Compounds

**Jeffery Steevens¹, Jacob Stanley¹, Allyson Harrison¹,
Ashley Harmon¹, Korampally Venumadhav²,
Shubhra Gangopadhyay², Keshab Gangopadhyay³**

**¹U.S. Army Engineer Research and Development Center;
²University of Missouri; ³Nems/Mems Works, LLC.**



NEMS/MEMS WORKS




BUILDING STRONG®

Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE MAY 2011		2. REPORT TYPE		3. DATES COVERED 00-00-2011 to 00-00-2011	
4. TITLE AND SUBTITLE A Novel MicroElectroMechanicalSystem (MEMS) Device for Passive Sampling of Hydrophobic Compounds				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Army Engineer Research and Development Center,Construction Engineering Research Laboratory,PO Box 9005,Champaign,IL,61826-9005				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited					
13. SUPPLEMENTARY NOTES Presented at the NDIA Environment, Energy Security & Sustainability (E2S2) Symposium & Exhibition held 9-12 May 2011 in New Orleans, LA.					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT Same as Report (SAR)	18. NUMBER OF PAGES 15	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

Problem


- Contaminant assessment (chemical analysis) for emergency response, clean up, and NRDAR has significant room for improvement
 - Current approaches are costly
 - Need for measures of bioavailability
 - Spatial and temporal challenges
- Few technological improvements in chemical analysis since NEPA in 1969
 - Example: Using approaches developed in 1970's, it is estimated the Deepwater Horizon spill cost around \$20 million to measure “non-detects.”



It is Time to Advance our Technology!

Technologies: Passive Samplers

- Passive samplers can be placed *in situ* to sorb contaminants; provide information about bioavailability




SPME fiber



ESTCP project, Reible and Lotufo


- Samplers are removed, extracted for CoC, analyzed
 - For organics: solid phase micro extraction (SPME) fibers, semi-permeable membrane devices (SPMD), polyoxymethylene (POM)
 - For metals: diffuse gradients in thin films (DGT)

Applications to Predict Bioaccumulation



SPME concentrations were predictive of tissue concentrations of PCBs in field-contaminated sediments and laboratory-spiked sediments

You et al. 2006, EST, 40: 6348



SPME concentrations were predictive of tissue concentrations of chlorinated hydrocarbons

Leslie et al. 2002, ETC, 21:229

SPME fibers can be used to predict bioaccumulation

Application in Risk Assessment

- Anniston Alabama Site
- Using passive samplers to assess bioavailability of PCB and confirm bioassay results




Technologies: Passive Samplers

- Uses:
 1. Measure bioavailability of CoC; direct measure of bioavailable fraction
 2. Use as a line of evidence (LOE) with in a weight of evidence approach
- Benefits: relatively easy and inexpensive; majority of cost is from chemical analysis
- Limitations: fragile, fouling, problems detecting compound on a small fiber

SPME fibers are an opportunistic technology; can we design a technology that intended for sampling contaminants?


Vision

- Develop a relatively inexpensive sampling device for a wide range of contaminants
- Could be used to sample or develop a detection system
- Immediate needs:
 1. Develop a sorbant surface with a high affinity for contaminants
 2. Robust and stable in environmental conditions
- Next steps:
 1. Detection
 2. Reporting



Sorbant Surface Material

- Sampler surface was fabricated using organosilicate nanoparticles ~ 3nm in size as the building blocks
- OSNP applied on a silicon substrate at different temperatures
 - 250-550°C



Polymethylsilsesquioxane (PMSSQ, ~ 3nm size), dispersed within polypropylene glycol (PPG).





Figure 3 a),b)Cross sectional SEM image of the NPO film c) AFM image of the NPO film surface

Cross section (SEM) and surface of OSNP (AFM)


The Sorbant Surface

- Surfaces applied to a silicon chip and characterized
 - 1 cm²
 - Around 1.5 μ m thick



Sample	Thickness
NPO-5555-250°C-5min	1689 nm
NPO-5555-350°C-5min	1535 nm
NPO-5555-450°C-5min	1439 nm

Image of NPO film and ellipsometry results



SPME

- Length: 2.5 cm
- Diameter: 230 μ m
- Surface area: 18 mm²



OSNP Surface


- Length: 1 x 1 cm
- Thickness: 1.5 μ m
- Surface area: 1800 mm²

100X increase in sorption surface area!

Testing the Surfaces

Goal: Compare the sorbtion of SPME versus OSNP Chips

- Step 1: prepare a test media (PCB153)
 - PCB 153 in water
 - Concentration using a passive “dosing” system
 - SPMD tube with 0.5 g of glyceryl trioleate (triolien) + 10 mg PCB
 - Achieves water concentration of around 0.0059 ± 0.002 ng/ml




SPMD with PCB in water and aeration

Testing the Surfaces


■ Exposure to surfaces

- Allow SPME and surfaces to equilibrate with water; 7 days with PCB 153 in water
- Remove and extract through procedure to dewater (methanol) then hexane
- Analyzed by GC-MS





1. How do surfaces compare in final concentration?
2. Is there a difference in time to reach equilibrium?

Results: Sorption of PCB 153 on Samplers




Field Deployable Device


- Developed and testing a field deployable device
 - OSNP surface in a steel chamber with screen
 - Current device is 100% teflon with silica OSNP surface
- Being tested at Anniston Site to compare to SPME data; for the purpose of supporting bioaccumulation and toxicity assessment



Conclusions



Nano Porous Organosilicate (NPO) Films



- Develop samplers for *in situ* analysis of CoCs
- Technology
 - Initial development focused on sorbent materials with increased surface area
 - Deployable devices that are robust and recoverable
- Future research focuses on integrated detection methods within a MEMs platform
- Help: Always need help with field test sites

Acknowledgements

- Colleagues at NEMS/MEMS and University of Missouri for fabrication of surfaces
- Research was funded, in part, by the Dredging Operations Environmental Research Program (DOER, Todd Bridges, PM)

